
FOLDING INSTRUCTIONS



- Push any corner in towards the opposite corner to reduce four walls to two double panels.
- Fold two panels together to form one flat tiered structure
- Hold vertically with hands 2/3 of the way up the frame. It is important that your hands remain in this position when folding.
- 4. Bend panels away from you until the top touches the base of the frame. Do not try to flatten during this bending action, you should instead be attempting to produce two curved vertical sections to either side of your legs. Stand close to the unit.
- 5. Take a step back and rotate hands 180° so thumbs are pointing towards you. Continue moving the top of the frame so that it now commences to curve past the base and towards your feet (into itself). Allow one of the two vertical curved sections to tuck inside the other.
- 6. By continuing to move the top of the frame towards you, the two vertical curved sections will collapse naturally on top of each other. Never forcefully bend the frame.
- 7. The 'Speedy' Change Shelter can now be placed into the carry bag.